



Scoring

I. Hrivnacova, IPN Orsay

Credits M. Asai (SLAC), G. Folger (CERN) and others

Geant4 School at IFIN-HH, Bucharest,
14 - 18 November 2016

Outline

- Extracting useful information
- Sensitive detectors, hits and hits collections
- Geant4 scorers
- Command-based scoring


Extracting Useful Information

- Given geometry, physics and primary track generation, Geant4 does proper physics simulation "silently".
 - You have to add a bit of code to extract information useful to you.
- The user action classes, if provided, are called by Geant4 kernel during all phases of tracking and have access to “theirs” Geant4 objects:
 - G4Run, G4Event, G4Track, G4Step

Geant4 and User Application


Event Processing

User classes are called during event processing and can collect the information about tracked particles from Geant4 objects



Geant4 and User Application Event Processing (2)

A special user class, sensitive detector, can be attached to (a) selected volume(s) and then called during event processing




Extracting Useful Information (2)

- During stepping, two user classes can be called
 - User stepping action – called in each step
 - User sensitive detector – called only when track passes a “sensitive” volume
 - Both have access to `G4Step`

Sensitive Detectors

Sensitive Detector

- A sensitive detector is assigned to a logical volume
- The sensitive detectors are invoked when a step takes place in the logical volume that they are assigned to



Defining a Sensitive Detector

- Sensitive detector objects are created and assigned to logical volumes in a user detector construction class in `ConstructSDandField()` function
- Creating SD object:

`MyDetectorConstruction.cc`

```
G4VSensitiveDetector* mySD  
= new MySD("MySD", "MyHitsCollection");
```

- Each sensitive detector object must have a unique name.
 - More than one sensitive detector instances (objects) of the same type (class) can be defined with different detector name
- Assigning to a logical volume via the volume name

```
// defined previously  
// G4VSensitiveDetector* mySD = ...  
SetSensitiveDetector("MyLVName", mySD);
```

- The `SetSensitiveDetector` function is defined in `G4VUserDetectorConstruction` base class (only since Geant4 10.x)

Sensitive Detector Class

- A sensitive detector is defined in a user class, **MySD**, derived from **G4VSensitiveDetector** base class
 - It defines the following user functions which are invoked by Geant4 kernel during event processing:
 - At **begin of event**: **Initialize()**
 - In **a step** (if in the associated volume): **ProcessHits(..)**
 - At **end of event**: **EndOfEvent(..)**
- Note that User stepping action defines only a function invoked when processing a step

Sensitive Detector Class (2)

```
#include "G4VSensitiveDetector.hh"
...
class MySD : public G4VSensitiveDetector {
public:
    MySD(const G4String& name
          const G4String& hitsCollectionName);
    virtual ~MySD();


    virtual void      Initialize(G4HCofThisEvent* hce);
    virtual G4bool    ProcessHits(G4Step* step,
                                   G4TouchableHistory* history);
    virtual void      EndOfEvent(G4HCofThisEvent* hce);
};
```

*The user functions
called by Geant4 kernel*

Hits and Hits Collections

A Hit

- Hit is a snapshot of the physical interaction of a track or an accumulation of interactions of tracks in the sensitive region of your detector
- Depending on your application you may be interested in various types information:
 - position and time of the step, momentum and energy of the track, energy deposition of the step, geometrical information, ...



User Hit Class

MyHit.hh

- You can store various types information by implementing your own concrete Hit class.
 - In this example we store the energy deposition of the step
- Typically for each information to be stored in a hit we add:

```
class MyHit
{
public:
    MyHit();
    // set/get methods; eg.
    void      SetEdep (G4double edep);
    G4double GetEdep() const;
private:
    // some data members; eg.
    G4double fEdep; // energy deposit
};
```

Data member	G4type fData;	G4double fEdep;
Set function	void SetData(G4type data);	void SetEdep(G4double edep):
Get function	G4type GetData() const;	G4double GetEdep() const;

Create a Hit

- A hit can be created when a step takes place in a sensitive logical volume, in a user sensitive detector function `ProcessHits(..)`

```
G4bool MySD::ProcessHits(G4Step* step,
                          G4TouchableHistory* /*history*/)
{
    MyHit* newHit = new MyHit();
    // Get some properties from G4Step and set them to the hit
    // newHit->SetXYZ();
    G4double edep = step->GetTotalEnergyDeposit();
    newHit->SetEdep(edep);
    // ...
    return true;
}
```

- Currently, returning boolean value is not used.
- The “history” will be given only if a Readout geometry is defined to this sensitive detector (the readout geometry is not presented in this course)

Hits Collections

- Many hits can be created during one event
- Hit objects must be stored in a dedicated collection
- Geant4 provides a dedicated class, `G4THitsCollection`, which allows to associate the hits collections with `G4Event` object and can be then accessed
 - through `G4Event` at the end of event, to be used for analyzing an event
 - through `G4SDManager` during processing an event, to be used for event filtering.
- When using Geant4 hits collections, the user hit class must derive from `G4VHit` base class
- Users may also define their own hits collections, eg.
 - Using STL library: `std::vector<MyHit>`
 - Using their application framework, eg. in the context of ROOT, it can be a ROOT collection (`TObjArray`, `TClonesArray`)

User Geant4 Hit Class

- Hits collection of a concrete hit class is defined as a specialization of the `G4THitsCollection` template class
 - Note the analogy of `G4THitsCollection<MyHit>` with `std::vector<MyHit>`
 - To avoid long names we define a name shortcut using **typedef**

MyHit.hh

```
#include "G4VHit.hh"
class MyHit : public G4VHit
{
    // the class definition as before
    // utility functions (called by Geant4)
    virtual void Draw();
    virtual void Print();
};
```

When using Geant4 hits collections, the user hit class must derive from `G4VHit`

```
#include "G4THitsCollection.hh"
typedef G4THitsCollection<MyHit> MyHitsCollection;
```

G4Allocator

- Creation / deletion of an object is a heavy operation.
 - It may cause a performance concern, in particular for objects that are frequently instantiated / deleted like hits.
- Geant4 provides **G4Allocator** class which provides functions for efficient memory allocation and de-allocation
 - It allocates a chunk of memory space for objects of a certain class.
- The same pattern can be used in all user classes, its is sufficient just to put the relevant user class name

G4Allocator (2)

MyHit.hh

```
#include "G4Allocator.hh"
class MyHit : public G4VHit {
    // ...
    inline void* operator new(size_t);
    inline void operator delete(void* hit);
    // ...
};
extern G4Allocator<MyHit>* MyHitAllocator;
inline void* MyHit::operator new(size_t) {
    return (void*)MyHitAllocator->MallocSingle();
}
inline void MyHit::operator delete(void* hit) {
    MyHitAllocator->FreeSingle((MyHit*)hit);
}
```

- The pattern (in green) can be cut & pasted in your hit (and other) classes
- Then you need just to replace **MyHit** with your class name

MyHit.cc

```
// ...
G4Allocator<MyHit>* MyHitAllocator;
// ..
```

Define Hits Collection (1)

```
void MySD::MySD(const G4String& name,  
                const G4String& hitsCollectionName)  
: G4VSensitiveDetector(name),  
  fHitsCollection(0)  
{  
  collectionName.insert(hitsCollectionName);  
}
```

- The name(s) of the hits collection(s) which is (are) handled by this sensitive detector is defined in the constructor
 - It is saved in the `collectionName` data member of the `G4VSensitiveDetector` base class
- In case your sensitive detector generates more than one kinds of hits (e.g. anode and cathode hits separately), define all collection names.

Define Hits Collection (2)

```
void MySD::Initialize(G4HCofThisEvent* hce)
{
    fHitsCollection
        = new MyHitsCollection (SensitiveDetectorName, collectionName[0]);
    G4int hcID
        = G4SDManager::GetSDMpointer()->GetCollectionID(collectionName[0]);
    hce->AddHitsCollection(hcID, hitsCollection);
}
```

- The hits collection object is created in **Initialize()**
 - This method is invoked at the beginning of each event
- The collectionID, **hcID**, is available after this sensitive detector object is constructed and registered to **G4SDManager**.
 - Thus, **GetCollectionID()** method cannot be invoked in the constructor of this detector class.
- It can be then attached to **G4HCofThisEvent** object given in the argument.
 - This object is then available via **G4Event** object

Filling A Hits Collection

- The hits are usually inserted in the hits collection when they are created

```
void MySD::SomeFunction(...)
{
    // Create a hit
    MyHit* newHit = new MyHit();
    // Set some properties to the hit
    // newHit->SetXYZ();
    // Add the hit in the SD hits collection
    fHitsCollection->insert(newHit);
}
```

MySD.cc

- Depending on the detector type `SomeFunction()` can be either `Initialize()` or `ProcessHits()`

Filling A Hits Collection (2)

- The way how the hits collections are filled depends on a detector type
- *A tracker detector* typically generates a hit for every single step of every single (charged) track
 - Hits are created in `MySD::ProcessHits()`
 - They typically contain
 - Position and time, energy deposition of the step, track ID
- *A calorimeter detector* typically generates a hit for every cell, and accumulates energy deposition in each cell for all steps of all tracks
 - Hits are created in `MySD::Initialize()`
 - They typically contain:
 - Sum of deposited energy, Cell ID

Iterate over A Hits Collection

```
void MySD::EndOfEvent(G4HCofThisEvent* /*hce*/)
{
    G4int nofHits = fHitsCollection->entries();
    G4cout << "Hits Collection: in this event there are "
            << nofHits << " hits " << G4endl;
    for ( G4int i=0; i<nofHits; ++i ) (*fHitsCollection)[i]->Print();
}
```

- The `MySD::EndOfEvent()` method is invoked at the end of processing an event.
 - It is invoked even if the event is aborted
 - It is invoked before `UserEventAction::EndOfEventAction`


Geant4 Scorers

Ready to Use Scoring Classes

- A typical quantities, such as energy deposit, track length etc. can be accounted using the classes already available in Geant4:
 - **G4MultiFunctionalDetector** – a sensitive detector which can be associated with scorers to account physical quantities
 - **Various scorer classes** are available:
 - G4PSTrackLength, G4PSEnergyDeposit, G4PSDoseDeposit, G4PSChargeDeposit, G4PSFlatSurfaceCurrent, G4PSNofSecondary, G4PSNofStep, ...
 - All scorer classes are derived from **G4VPrimitiveScorer** base class
 - See Application Developers Guide 4.4.5 for the complete list
 - **Filter classes** can be used to apply a selection on the quantities to be accounted:
 - G4SDCharged[Neutral]Filter, G4SDParticleFilter, G4SDKineticEnergyFilter, ...
 - The filter classes are derived from **G4VSDFilter** base class
 - See Application Developers Guide 4.4.6 for the complete list

Example B4d

- An example of use of Geant4 scorers is provided in basic example B4d
- **G4MultiFunctionalDetector**
- Scorers accounting energy deposit and track length:
G4PSEnergyDeposit,
G4PSTrackLength
- Filter to select charged particles:
G4SDChargedFilter



Command-based scoring

Command-based scoring

- Command-based scoring functionality offers the built-in scoring mesh and various scorers for commonly-used physics quantities such as dose, flux, etc.
 - Due to small performance overhead, it does not come by default.
- To use this functionality, activate the `G4ScoringManager` after the instantiation of `G4RunManager` in your `main()`
- This will create the UI commands of this functionality in `/score` directory.

```
#include "G4ScoringManager.hh"
int main()
{
    // ...
    G4RunManager* runManager = new G4RunManager;
    G4ScoringManager::GetScoringManager();
    // ...
}
```

Command-based Scoring

Example Macro

```
# Define scoring mesh  
/score/create/boxMesh boxMesh_1  
/score/mesh/boxSize 100. 100. 100. cm  
/score/mesh/nBin 30 30 30  
  
# Define scoring quantity  
/score/quantity/energyDeposit boxMesh  
keV  
  
# Define a filter  
/score/filter/charged  
  
# Close mesh  
/score/close
```


3D scoring mash:
name, shape&size, number of bins

Scoring quantity:
energyDeposit

Filter:
charged particles only

Close mash

Command-based Scoring Examples (2)



Summary

- The Geant4 toolkit provides dedicated classes/tools for user scoring:
 - Sensitive detectors
 - Geant4 scorers
 - Command-based scoring